



NOTE:
Tubing should always run straight and level in both horizontal and vertical directions. Do not bend, bow or curve tubing during installation.